


hidrotermal[®]



Model: Hidro-CTRL

UNDERWATER LIGHT REMOTE CONTROLLER

USER MANUAL



- **NORMAL:** Power Switch Function, Press the key for turning on or turning off the light.
- **RANDOM:** Reset function, the light can return to the first mode when press this key at any working mold.
- **P+:** Forward key for changing the modes, the light can turn to next working mode when pressing this key.
- **P-:** Backward Key for changing the modes, the light can turn back to previous working mode when pressing this key.
- **S+/S-:** There are total 10 adjusting levels for color changing speed. Adjust it by pressing S+ or S-. That function is only effective in the program for color flashing or changing.

